











User Manual

Accessories and Assembly Instructions




Accessories

	Name		Quantity
A	Top Pole		2
B	Mild Pole		1+1
C	Bottom Pole		2
D	Net		1
E	Guide rope		2
F	Shuttlecock		2
G	Badminton racket		4
H	Tension Handle		1
I	Bag		1


Assembly Instruction

Step 1: BEFORE ASSEMBLY


1. Find a clean, level place to begin the assembly of your product.
2. Verify that you have all listed parts as shown on the part list pages.
3. Connect the top, mid and bottom parts of the aluminum pole.




Step 2: Lay the net on the ground




Step 3: Pass the top part of pole through the side of the net.




Step 4: Connect the upper and bottom parts of the aluminum pole, and pass one end of the pole on the net side through the eyebolt set, and connect it to the tension adjuster. The other end is attached to the eyebolt set.



Step 5: Fasten the carabiner on the guide rope and the eyebolt set on the aluminum pole, and nail the needle on the guide rope to the ground, to make that the distance between the single guide rope and the two ground nails is 3 to 4 feet. Then, erect the aluminum poles, keep them vertical, adjust the guide rope to fix the erected aluminum poles.



Step 6: Adjust the tension adjuster to straighten the net.
Operation of tension adjuster as following:



TIP: After the net is assembled, the net can be tightened by adjusting the Tension handle.

